

請注意：

為提高消費者組裝便利性，X7主旋翼夾頭內的T10x18x5.5止推軸承3片組，其中內外徑較大的止推軸承蓋已預先壓入主旋翼夾頭內，組裝時請對照說明書P. 24 組裝順序組裝。

Note:

In order to improve the convenience for assembling the X7 main rotor head, the thrust bearing cap (with bigger inner race) is preassembled into the main blade grip. Please assemble the thrust bearing as illustrated in the manual (P. 24).

